

Lab7 description



System A

- For System A, you can perform the lab portion using only a Launchpad board.
- When the '1' key is pressed, display the menu on the serial terminal once as follows:

- | |
|-----------|
| 1. List |
| 2. Name |
| 3. Temp |
| 4. Center |
| 5. Left |
| 6. Right |

- If a '2' key is pressed, display "ESET 369: " plus your name(s) on the serial terminal.
- If a '3' key is pressed, read the ADC value from the internal temperature sensor and display it on the serial terminal in Fahrenheit (°F) once.
- Fill out the following table when measured. Take two measurements. Take a photo showing one of these values when measured. Make sure to include this (1) table and (2) photo showing the value in your lab report.

	Temperature (°F)
Case 1	
Case 2	

(Note) Take a photo showing this value

System B

- **For safety, please, remember and make sure to unplug your Launchpad from the USB port before making any hardware changes.**
- Connect jumper wires as shown in Figure 1.






Figure 1. Connection diagram



- Students need to write a C/C++ program to read the input character from their serial terminal and to perform the relevant functions in Table 1.

Keyboard input	Functions
'1' key	<p>When the '1' key is pressed, display the menu on the serial terminal once as follows:</p> <div> <ol style="list-style-type: none"> 1. List 2. Temp 3. Name 4. Center 5. Left 6. Right </div>
'2' key	Display "ESET 369: " plus your name(s) on the serial terminal.
'3' key	Read the ADC value from the internal temperature sensor and display it on the serial terminal in Fahrenheit (°F)
'4' key	Servo motor shaft at a neutral position. Let's say this is 0 degrees.
'5' key	Control the servo motor shaft to rotate about -45 degrees.
'6' key	Control the servo motor shaft to rotate about +45 degrees.

Table 1. Functions

- There is an empty battery pack in the lab kit box. If the system is functional, you don't need to use a power supply once the hardware connection and the function are initially checked and confirmed. You can switch to a battery pack instead. It needs 6 AA batteries. Please bring your own batteries.
- Make sure to complete the lab check-off assignment (Lab7-50X) posted on CANVAS before the given deadline. The code files should be submitted as a part of the lab check-off assignment. Laboratory assignment deadlines are 15 minutes before the end of your registered laboratory session.

Reference

- B. Hur, "Learning Embedded Systems with MSP430 FRAM microcontrollers", 2nd ed. 2023.